# Peppers Cable Glands Ltd. Stanhope Road, Camberley, GU15 3BT, UK


## CR-X\*\* Type Compound Filled Cable Glands - ASSEMBLY INSTRUCTIONS

#### Brief Description

Peppers CR-X\*\* type Compound-filled cable glands are for outdoor use in the appropriate Hazardous Areas with unarmoured cable of any construction, with or without braids or screens, where the braids or screens pass through the compound. They may also be used as a line bushing for terminating flying leads or for the direct inter-connection of associated enclosures. A variant giving electrical continuity to a lead sheath is available. They give environmental protection to IP66, IP68 (100 metres for 7 days) and Deluge.

#### Warning

Please read these instructions carefully. These products should not be used in applications except as detailed here or in our datasheets unless confirmed in writing by Peppers. Peppers take no responsibility for any damage, injury or other consequential loss caused where products are not installed or used according to these instructions. This leaflet is not intended to advise on the selection of product. Further guidance can be found in the standards listed overleaf or the prevailing code of practice. The compound used within this cable gland has application limitations and may be adversely affected by some solvent vapours. If such vapours are likely to be present when the cable gland is in service, necessary precautions should be taken. Peppers Technical Datasheet can be downloaded from our website for further guidance. Prior to use the compound should be stored in its original packaging in a dry area at temperatures between 5°C and 21°C.



### STEP-BY-STEP FITTING INSTRUCTIONS

- Split gland as shown. Warning the entry body of this cable gland is coated with a releasing agent to ensure the compound form can be inspected after curing. The entry body should not be treated with any lubricant or be exposed to any solvents. The internal bore of the entry body must not be damaged. Any handling during the course of normal installation will not affect the operation of the releasing agent.
- 2. Fit Entry Body, allowing for any installation accessories, and fully engage the thread into the equipment. Hand-tighten, then suitably secure with a wrench. Further guidance can be found in Peppers document CT0030 which can be found on our website.
- 3. Slide Rear onto cable as shown.
- 4. CABLE PREPARATION

Strip jacket so that the cores are fully exposed in the compound chamber, to a length to suit the installation. Lead sheath must be cut to push through the continuity washer. Remove protective foils, and any cords/fillers from around and between the cores. Take care not to cut the insulating sleeves of the cores. Pigtail and sleeve any screens to be passed through compound.

HEALTH AND SAFETY WARNING: The resin used in the compound can cause eye and skin irritation. For your personal protection, wear the gloves supplied whilst in contact with the compound. A COMPREHENSIVE SAFETY DATA SHEET IS AVAILABLE FOR DOWNLOAD FROM OUR WEBSITE.

- 5. Check compound has not passed its "Use By" date. It has a work life of about 30 minutes at 16-27°C (60-80°F), during which time it can be worked and shaped before it begins to cure. Full cure takes 24 hours at 16-27°C (60-80°F). Lower temperatures will require a longer cure time. E.g. at 3°C (37°F) full cure takes about seven days. It is recommended to mix the putty and pack the fitting at 20°C (68°F). Minimum mixing/packing temperature is 10°C. Minimum curing temperature is 3°C.
- 6. Trim any hardened pieces from the ends of the sticks. Mix the compound by rolling, folding and breaking. Ease mixing by cutting large sticks in half. Fully mixed compound has a uniform colour with no streaks. See Figure 1 for correctly mixed compound.
- 7. Support the cable and Rear Assembly, holding them roughly concentric. Any lead sheath is pushed through the continuity washer ensure that contact has been made. Splay out the cores. Starting in the middle, pack small amounts of rolled-out compound between the cores. Re-straighten each core and work outwards until all gaps are filled. Bundle the cores with cord or tape (see figure 2) so they are not disturbed. Pack around the outside of the outer cores to completely fill the Rear Assembly Cup. Build up compound around the outside of the cores, with a slight taper and to the approximate compound length shown in the diagram & Table 1. Where the cable has a large quantity of cores ensure they are bundled near to the gland entry thread.
- 8. Pass cores through & push compound into the Entry Body until the Rear Assembly engages. Remove squeezed out compound at arrow A. Support the Back Nut and screw the Union Nut seven full turns onto the Entry Body (arrow B). Ensure that compound emerges at the entry thread (arrow C).
- 9. Clean off excess compound from the Entry Body to allow withdrawal when cured (arrow C). Cores may be disturbed after 1 hour. Leave to cure for 4 hours when working at 21°C.
- 10. To release the compound for inspection, unscrew the Union Nut. Using a wrench on the Back Nut, rotate the Back Nut back and forth whilst pulling the rear assembly away from the entry body. This will release the compound from the entry body. Do not over rotate as this may damage cable conductors. Pull the Back Nut and compound out for inspection. The compound should appear as in Figure 3 with no gaps, holes or cracks.
- 11. Hand-tighten Union Nut to remake joint. Then refer to Table 2 and tighten using a wrench to the given amount.
- 12. The equipment should not be energised until the compound has been left to cure for at least 4 hours when working at 21° C. See chart, Compound Cure Time vs. Temperature for further guidance.

 Issue: 20
 Doc: PA113

 Date: 11/03/2025
 www.peppers.co.uk
 Page 1 of 2

# Peppers Cable Glands Ltd. Stanhope Road Camberley GU15 3BT UK

## CR-X\*\* Type Compound Filled Cable Glands - ASSEMBLY INSTRUCTIONS









Table 2 Tightening information (step 10), Cable Sizes and Permitted Cores						
Stopper Box Size	Tighten Union Nut with Wrench	Max. Ø Over Cores	Max. No. of Cores	Max. Outer Sheath Ø		
20S	½-turn	10.4	35	11.7		
20	½-turn	12.5	40	14.0		
25	½-turn	17.8	60	20.0		
32	½-turn	23.5	80	26.3		
40	½-turn	28.8	130	32.2		
50S	½-turn	34.2	200	38.2		
50	½-turn	39.4	400	44.1		
63S	½-turn	44.8	400	50.1		
63	½-turn	50.0	425	56.0		
75S	½-turn	55.4	425	62.0		
75	½-turn	60.8	425	68.0		
80	¾-turn	64.4	425	72.0		
85	¾-turn	69.8	425	78.0		
90	¾-turn	75.1	425	84.0		
100	³⁄₄-turn	80.5	425	90.0		



Approval	Certificate Number	Protection Concept / Type
ATEX (2014/34/EU)	CML 19ATEX1344X / CML 21UKEX1031X	(Ex) I M2 II 1D 2G Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex ta IIIC Da
UKCA (SI 2016 No. 1107)	CML 19ATEX4114X / CML 21UKEX4037X	(Ex) II 3G Ex nR IIC Gc
IECEx	IECEx CML 19.0046X	Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex nR IIC Gc / Ex ta IIIC Da
CSA	1356011	Ex db IIC Gb / Ex eb IIC Gb / Ex ta IIC Da Class I Zone 1 AEx db IIC Gb / Class I Zone 1 AEx eb IIC Gb / Zone 20 AEx ta IIIC Da CL I Div 2 Gr ABCD / CL II Gr EFG / CL III Type 4X IP66 IP68
INMETRO	NCC 13.2188 X	Ex db   Mb / Ex db   IC Gb / Ex eb   Mb / Ex eb   IC Gb / Ex nR IIC Gc / Ex ta IIIC Da
EAC	ПРОММАШ TECT RU C-GB.АЖ58.В.05106	PB Ex db I Mb X / 1Ex db IIC Gb X / 1Ex eb IIC Gb X / PB Ex eb I Mb X / 2Ex nR IIC Gc X / Ex ta IIIC Da X
UKRAINE	СЦ 18.0322 Х	I M2 Ex db I Mb / Ex eb I Mb / II 1D 2G 3G Ex db IIC Gb / Ex eb IIC Gb / Ex nR IIC Gc / Ex ta IIIC Da
CCC	2021312313000407	Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex nR IIC Gc / Ex ta IIIC Da IP66
CCoE (PESO)	P494321/18 & P494321/20	Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex nR IIC Gc
ECASEx	25-06-153223/E25-06-159811/NB0007	Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex nR IIC Gc / Ex ta IIIC Da
ABS	25-0158110-PDA	Specified ABS Rules – See certificate
Lloyd's Register	LR2124442TA	Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex nR IIC Gc / Ex ta IIIC Da
DNV	TAE00004XK	Ex db I Mb / Ex db IIC Gb / Ex eb I Mb / Ex eb IIC Gb / Ex nR IIC Gc / Ex ta IIIC Da

#### Installation Guidance

Point	Advice						
1	BS/EN/IEC 60079-10 BS/EN/IEC 60079-14 National Electrical Code (NEC 500-505) Canadian Electrical Code (CSA C22.1)						
2	Installation should only be carried out by a competent electrician, skilled in cable gland and appropriate electrical installations.						
3	Comprehensive details of the compliance standards can be found in the product certificates which are available for download from our website.						
4	NO INSTALLATION SHOULD BE CARRIED OUT UNDER LIVE CONDITIONS.						
5	Threaded entries: the product can be installed directly into threaded entries. Threaded entries should comply with the relevant applicable standards and have a lead-in						
	chamfer to allow for full engagement of the threads. Failure to provide a sufficient lead-in chamfer may lead to ingress sealing issues. For Ex db applications a minimum of 5						
	fully engaged threads is required.						
6	Clearance holes: these shall be no larger than 0.7mm above the nominal diameter of the external entry thread. The product should be secured with a Peppers locknut and						
	then tightened to ensure the cable gland is secure. Where no integral sealing method is provided a Peppers sealing washer should be used to maintain IP ratings. A Peppers						
	serrated washer should be used for additional installation protection. Peppers does not recommend using tapered threads in clearance holes.						
7	Ingress protection: to maintain the Ingress Protection rating of the product, the entry hole must be perpendicular to the surface of the enclosure. The surface should be clean,						
	dry and must be sufficiently flat and rigid to support the assembly and make the IP joint. Metric threads are supplied with an O-ring and will maintain IP66 and IP68. Other						
	parallel entry threads will maintain an IP rating of IP64. A Peppers sealing washer should be used to maintain all IP ratings greater than IP64. Whilst Peppers products with						
	tapered threads, when installed into a threaded entry, have been tested to maintain IP66 without any additional sealant, due to the differing gauging tolerances associated						
	with the use of tapered threads it is recommended to use a non-hardening thread sealant if an IP rating higher than IP64 is required. Any thread sealant used should be						
	suitable for use in the hazardous area or location where the equipment is installed, have a suitable temperature range for the temperature at the point of mounting, not contain						
	evaporating solvents and not cause corrosion at the threaded interface when used with dissimilar materials. The product incorporates a thread run out according to general machining techniques and will not have a full form thread for the entire length. Threaded entries should have a suitable lead-in chamfer to ensure a seal is maintained, further						
	guidance can be found on Peppers website. It is the user's/installer's responsibility to ensure that the interface between the enclosure and cable gland is suitably sealed for						
	the required application.						
8	Where a bonding connection to earth is required a Peppers earth tag should be used. Peppers earth tags have been independently tested to comply with the Category B						
	values given in IEC 62444. Peppers earth tags should be fitted over the external entry thread from either inside or outside the enclosure. If fitted internally they must be						
	secured with a Peppers locknut and optionally a Peppers serrated washer. Further guidance can be found in Peppers document CT0170 which can be found on our website.						
9	Peppers external metric entry threads comply with ISO 965-1 & ISO 965-3 with a 6g tolerance fit. The standard metric thread pitch is 1.5mm for threads up to M75 and 2.0mm						
	for size M80 and above. Alternative thread pitches are available upon request. Peppers external NPT threads comply with ASME B1.20.1 with gauging to clause 8.1. All						
	threads comply with the threaded joint requirements of clause 5.3 from IEC 60079-1. Information on other thread types can be found in the product certificates.						
10	Once installed do not dismantle except for routine inspection. An inspection should be conducted as per IEC 60079-17. After inspection the gland should be re-assembled as						
	instructed, ensuring the compression nut, mid cap and back nut are correctly tightened to ensure the cable is secure.						
11	The O-ring that is fitted to the outer diameter of the Rear Assembly Cup (visible on figure 3) is to prevent compound from extruding inside the gland during the assembly						
	process. It has no other function and does not contribute to the protection concept or ingress protection rating of the cable gland.						
12	If required an anti-seize lubricant may be used to aid assembly and routine inspection, if used care should be taken to ensure no lubricant comes into contact with the cable						
	gland seals as this may impair performance. Any lubricant used should comply with the prevailing code of practice, be suitable for use in the hazardous area or location where						
	the equipment is installed, have a suitable temperature range and not contain evaporating solvents.						

## Interpretation of Markings

Markings on the outside of this gland carry the following meanings: Cable Gland Type & Size CR-X-2-a-bbb-ccc-nn.

	9 ,	0 71		
2 =	Optional continuity washer for lead sheathed cable		bbb	Gland size
a =	Main component material	B = Brass	ccc	Entry thread type and size
		S = Stainless Steel	nn	Year of manufacture

## **Specific Conditions of Use**

- CR-X\*\* glands must not be used in enclosures where the temperature at the point of contact is outside the range of -60°C to +135°C.

  The interface seals comply with the requirements of the standards listed the certificates above when CR-X\*\* glands are fitted to a representative enclosure having a smooth flat mounting surface. In practice the interface between the male thread of the glands and their associated enclosure cannot be defined, therefore it is the user's responsibility to ensure that the appropriate ingress protection level is maintained at these interfaces
- When used in explosive dust atmospheres and installed in threaded entries without interface O-ring seals, CR-X\*\* glands shall only be fitted into enclosures that have either:
  - parallel entries that will ensure a minimum of 5 full threads of contact will be maintained, this is in accordance with clause 5.1.2 of IEC 60079-31. tapered entries that will ensure a minimum of 3 ½ full threads of contact will be maintained, this is in accordance with clause 5.1.2 of IEC 60079-31.





























